





		POW_PA	BAND_SEL	RX_SEL
STAND BY		L	L	L
EGSM_RX		L	H	H
DCS_RX		L	H	L
EGSM_TX		H	H	L
DCS_TX		H	H	H


TX Module S/W Control Circuit



RF Part




FM_RADIO





LCD BACKLIGHT

VIBRATOR




JTAG_BD

Title RF / FM RADIO / LCD BACKLIGHT		
	Document Number GT-E1200(Eider)	REV0.3
Date:	Sheet	1 of 3




MEMORY(64Mb+32MB)



OVP & BTC

Title		Baseband IC / MEMORY	
Document Number	GT-E1200(Eider)	REV0.3	
Date:		Sheet	2 of 3



POWER KEY

KEY MAP



LCD CONNECTOR

TORCH DRIVER



SPEAKER



MAIN_MIC